


COVE Setup Quickstart Guide

01




INSTALLER:

Install mounting bracket and connect wiring to the terminals in accordance with local codes. Use 60A-rated copper conductors. COVE requires 208-240V, measured from L1 to L2.

Tighten the terminal block to the recommended torque:

- 45 in-lb (5.1 N-m) for power wires
- 40 in-lb (4.5 N-m) for ground wires

02



INSTALLER:

Align COVE to the mounting bracket and insert, ensuring COVE is fully seated and flush to the wall. Secure COVE to the mounting bracket using the provided screws. Fasten using a Phillips driver.

03

SCAN TO DOWNLOAD




evercharge.com/cove-setup

INSTALLER & OWNER:

Download the EverCharge App.

COVE Setup Quickstart Guide


04



INSTALLER:

Set COVE's breaker size. To set breaker size, open the EverCharge app → Device List → Set Up New Device.


05



OWNER:

Connect COVE to a wireless network. To connect to a wireless network, open the EverCharge app → Device List → Set Up New Device → Enter WiFi password.

06



OWNER:

You're all set!
Just plug in and enjoy the charge.